


Scenery curtains:

In just a few easy steps your stage event will acquire professional surroundings. The stable and infinitely vertically adjustable scenery curtains can easily be installed to all models of our mobile stages.


The **fixed stage drapes** mounted onto the stage are infinitely vertically adjustable to a height of 250cm. Even more stability is provided by the **scenery brackets**, which connect the **fixed stage drapes**.



Our mobile stage drapes are installed individually:

They are infinitely vertically adjustable between 200 and 350cm, the 200cm wide curtain parts are ideal, for example for the positioning of alley ways at the side of the stage. The actors can stay or get changed 'hidden' directly next to the stage. In addition the **mobile stage drapes**, which serve to practically conceal, are very easily installed at the sides of the stage.

The material of the curtains is chosen individually.





Free standing, steel pipe, powder coated in dark black (RAL 9005). Height is infinitely vertically adjustable

from 200 to 350cm including Velcro for the mounting of the stage curtain.

Width: 200 cm Height: infinitely vertical adjustable to 350cm



□ Curtain

For stage drapes with velour band, sewn smoothly, Molton R 55, pure cotton, tested flame resistance according to DIN 4102 B!. Opaque and sound absorbent.

Weight: approx.300 g/m²
Width: approx. 200 cm

Colours: black, grey, white, blue, light grey, dark blue, red

fixed: Width: 200 cm Height: 250 cm

Height: 250

mobile: Width: 200 cm Height: 350 cm

■ Fastening to the edge of the stage

stands also increase stability.

The **fixed stage drapes** are directly fastened to the parts of the stage. Stability is provided by the threaded slide piece which is slid into the montage groove.


The welded pressure parts on the



Scenery brackets

In order to connect the **fixed stage drapes** under each other to the parts of the stage, we have developed the **scenery brackets**. The brackets are fastened to the outer stands of the stage parts with two winged screws; this prevents swinging of the scenery curtains.

--





--

